

COMPACTOR – HOW TO USE

3 EASY STEPS:



1 OPEN door(s) & DEPOSIT materials

2 CLOSE door(s)

3 TURN knob to START and HOLD for 5 seconds



WHAT TO DO if compactor does not turn on:

1 Check that the DOORS are CLOSED



The red magnets at the top of each door must sense each other.

2 TURN knob to RESET



3 TURN knob to START and HOLD for 5 seconds



Any issues, contact
Apex Mountain Resort at 250-292-8222 (Press 0)